

Register your product and get support at

www.philips.com/welcome





52PFL7404H
47PFL7404H
42PFL7404H
32PFL7404H
52PFL5604H
47PFL5604H
37PFL5604H

Quick

Start




PHILIPS




1


1




2





3




4



5




2




3







1






2








3






4













Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2009 © Koninklijke Philips Electronics N.V. All rights reserved.

